

New security policy

The default password was changed!

To increase security, the router is produced with a unique default password. This password is printed out on the label of the router. The format of the password is:

P<last 8 digits of the serial number>h

To maintain the security of your network, always change the default password of the router! Please note that the setting of some features is not possible until the default password is changed. The password can be set back to the default one by performing the factory reset of the device.



HIRSCHMANN

A **BELDEN** BRAND